

Dispatcher Software

Mini PTT Server Setup > Dispatcher Software

Search Dispatcher Software

New ▾

Sort ▾ View ▾

Details

Name	Date modified	Type	Size
AxInterop.MapWinGIS.dll	2023-12-08 12:22	Application extens...	76 KB
dLogs	2023-12-2		
Interop.MapWinGIS.dll	2023-12-0		
MapWinGIS-v5.1.1-Win32	2023-12-0		
mwtiles.db3	2023-12-1		
Newtonsoft.Json.dll	2023-12-0		
Radio Remote Dispatcher	2023-12-08 12:22	Application	2,185 KB
syslock	2023-12-28 15:15	Configuration setti...	0 KB

SERVER IP : CUSTOM IP ▾ **CONNECT**

Enter IP :

UserName:

Password:

Close

[MINI PTT DISPATCHER LOGIN SCREEN]

FileSettingsConfiguration

SETTINGS PANEL

CONTROL-STATIONSMOBILE APP USERSGROUPS

S.No.	Name	ID	Type	Connection	Signal	Speaker
1	ROIP-1	40	ANALOG	<div></div>	<div></div>	<div></div>
2	ROIP-2	41	ANALOG	<div></div>	<div></div>	<div></div>
3	ROIP-3	42	ANALOG	<div></div>	<div></div>	<div></div>
4	ROIP-4	43	ANALOG	<div></div>	<div></div>	<div></div>

SERVER CONNECTION STATUS

CONNECTED ROIP

CONNECTED MOBILE APPS

CONNECTED MOBILE APPS

PADEL DIS

29-Dec-2023

15:31:06

Mute AllUnmute All

IDLE













DISABLED

PADEL DISABLED

[MINI PTT DISPATCHER HOME SCREEN]

File
Settings
Configuration

CONTROL-STATIONS
MOBILE APP USERS
GROUPS

S.No.	Name	ID	Type	Connection	Signal	Speaker
1	ROIP-1					
2	ROIP-2					
3	ROIP-3					
4	ROIP-4					

Add to Call
Add to Multi-Call
Add to Group-Call
Show
Broadcast Call

INCOMING SIGNAL
OUTGOING SIGNAL

MUTE
UNMUTE

Mute All
Unmute All

INCOMING AUDIO from ROIP-1

MUTE

PUSH TO TALK

ROIP-1

Clear All







START ANNOUNCEMENT

CLEAR CALL SCREEN
START ANNOUNCEMENT

CONNECTED
CONNECTED :: [2 Mobile App: 0]
PADEL DIS
29-Dec-2023
17:00:59

PADEL DISABLED

[CALLING SCREEN]

S.No.	Name	ID	Type	Connection	Signal	Speaker
1	ROIP-1	40	ANALOG			
2	ROIP-2		ALOG			
3	ROIP-3		AI			
4	ROIP-4		AI			

Add to Call

Add to Multi-Call

Add to Group-Call

Show



Broadcast Call


ROIP-1

IP:0.0.0.0

Port:0

ID:40





PTT

POP-UP
SCREEN

CONNECTION
STATUS

AUDIO
MUTE/UNMUTE

PTT BUTTON
TO CALL


Mute All

Unmute All

IDLE

DISABLED

PADEL DISABLED



S.No.	Name	Alert	ID	Type	Connection	Signal	Speaker	Current Selection	Assigned Range	Location	Last Location Time
1	App-1	SOS(05:30:00)	1000	MOBILE APP	<div></div>	<div></div>	<div></div>	USER: App-2	Not Assigned	28.4704002 77.0905742	15:39:11
2	App-2		1001	MOBILE APP	<div></div>	<div></div>	<div></div>	GROUP: Control Sta...	Not Assigned	28.4710177 77.0930866	15:38:37
3	App-3		1002	MOBILE APP	<div></div>	<div></div>	<div></div>		Not Assigned	Not Available	
4	App-4		1003	MOBILE APP	<div></div>	<div></div>	<div></div>		Not Assigned	Not Available	

Fetch GPS History

Add to Call

Add to Multi-Call

Disable App

Clear Alert

ENABLE/ DISABLE APP

FETCH GPS HISTORY

ADD TO CALL

ADD TO MULTI-CALL

CLEAR SOS ALERT

S.No.	Name	Alert	ID	Type	Connection	Signal	Speaker	Current Selection	Assigned Range	Location	Last Location Time
1	App-1	SOS(05:30:00)	1000	MOBILE APP	<div></div>	<div></div>	<div></div>	USER: App-2	Not Assigned	28.4704438 77.0905594	15:38:11
2	App-2		1001	MOBILE APP	<div></div>	<div></div>	<div></div>	GROUP: Control Sta...	Not Assigned	Not Available	
3	App-3		1002	MOBILE APP	<div></div>	<div></div>	<div></div>		Not Assigned	Not Available	
4	App-4		1003	MOBILE APP	<div></div>	<div></div>	<div></div>		Not Assigned	Not Available	

DISABLED APP

SOS ALERT

MOBILE
APP ID


CONNECTED

DISCONNECTED

SELECTED GROUP/
APP USER

LOCATION

LAST
LOCATION
TIMING



S.No.	Name	ID	Sharing
1	Control Station Group-1	1	OFF
2	Control Station Group-2	2	ON

CALL

Enable Audio Sharing

Disable Audio Sharing

Show

CREATED CONTROL STATION GROUPS

CALL GROUP

ENABLE AUDIO SHARING

DISABLE AUDIO SHARING

GROUP ID

AUDIO SHARING OFF

AUDIO SHARING ON

Mute All

Unmute All

IDLE

DISABLED

PADEL DISABLED

FileSettingsConfiguration

CONTR

S.No

1

2

3

4

Sound Configuration

Connection Settings

Change Password

Live Location

Create Geo-Fence

Update GPS/Geo-Fence

Announcement Configuration

PS

	Type	Connection	Signal	Speaker
	ANALOG	<div></div>	<div></div>	<div></div>
	ANALOG	<div></div>	<div></div>	<div></div>
	ANALOG	<div></div>	<div></div>	<div></div>
	ANALOG	<div></div>	<div></div>	<div></div>

Mute All

Unmute All

IDLE

DISABLED

PADEL DISABLED

SOUND CONFIGURATION SETTINGS

LIVE LOCATION

UPDATE GPS/GEO-FENCE

CREATE GEO-FENCE

ANNOUNCEMENT SETTINGS

CONNECTED

CONNECTED :: [2 Mobile App: 0]

PADEL DIS

02-Jan-2024

11:12:07

[MINI PTT DISPATCHER HOME SCREEN]

AUDIO CONFIGURATION

Select Audio Input Device Select Audio Output Device

Microphone Speakers

Audio Input Level Audio Output Level

Audio Input Level slider Audio Output Level slider

Select Audio Codec Select Tx Audio Packet Size

G.711 ALAW (64Kbps) 512

PTT BUTTON TYPE

Hold To Talk : ☒ Toggle On/Off : ☐

Save **Close**

MICROPHONE → ← **SPEAKER**


MICROPHONE LEVEL → ← **SPEAKER LEVEL**

AUDIO CODECS → ← **PACKET SIZE**


← **PTT BUTTON TYPE SETTINGS**

[Sound configuration Settings SCREEN]





[Create GEO-FENCE SCREEN]



[Create GEO-FENCE SCREEN]

Update Geo-Fence Mapping

—□×

App User :

App-1

←

APP USER

Shape :

Shape-1

←

GEO-FENCE
SHAPE

Gps Timer :

30

☒

←

GPS TIMER

Save

Close

[UPDATE GPS/ GEO-FENCE]

